

---

# Maytag 3000 Series Washer F 21

---

*Downloaded from  
Maytag 3000 [everybodystreet.com](http://everybodystreet.com)  
Series by Arellano &  
Washer F 21 Greyson*

---

## UNDERSTANDING THE MAYTAG 3000 SERIES WASHER F 21 ERROR CODE

---

If you own a **Maytag 3000 Series Washer** and see the dreaded **F 21** error code flashing on the display, you are not alone. This code is one of the most common issues reported by users of this popular front-load and top-load washing machine series. The **Maytag 3000 Series Washer F 21** error indicates a prolonged drain time—essentially,

the machine's control board has detected that the water is not draining quickly enough or at all. This can be a frustrating interruption to your laundry routine, but the good news is that the problem is often simple to diagnose and fix without calling a technician. In this comprehensive guide, we will walk you through the meaning of the F21 code, the most frequent causes, step-by-step troubleshooting methods, preventive maintenance tips, and when it is time to seek professional help. By

the end, you will have the knowledge to tackle this error with confidence.

---

### **WHAT DOES THE F21 ERROR CODE MEAN ON A MAYTAG 3000 SERIES WASHER?**

---

The error code **F 21** on a Maytag 3000 Series washer stands for “Long Drain” or “Extended Drain Time.” The washer’s control system monitors how long it takes to drain water during the spin cycle. If the water level does not drop sufficiently within a set period—typically around eight minutes—the machine pauses the cycle and displays the error. This is a safety feature designed to prevent the motor from overheating or

damaging the pump. The **Maytag 3000 Series Washer F 21** code can appear at the beginning of a cycle, after a wash, or during the final spin, and it usually halts operation until the issue is resolved.

## **Why Drain Time Matters**

A washing machine relies on a pump to expel water after each wash and rinse. If the pump is clogged, the drain hose is blocked, or the drain pump is failing, water remains inside the drum. The control board expects the water level to drop quickly; when it does

not, it triggers the F21 alert. Understanding this mechanism is key to systematic troubleshooting.

---

### **COMMON CAUSES OF THE MAYTAG 3000 SERIES WASHER F 21 ERROR**

---

Several factors can cause the **Maytag 3000 Series Washer F 21** error. Most are related to drainage issues, but a faulty control board or wiring problem can also be responsible. Below are the most frequent culprits:

- **Clogged Drain Pump Filter:** Lint, coins, small clothing items, and debris can accumulate in the pump filter, restricting water flow.
- **Blocked or Kinked Drain Hose:** The hose that carries water from the washer to the standpipe or utility sink may be twisted, crushed, or filled with debris.
- **High Drain Standpipe or Improper Drain Setup:** If the standpipe is too high (above 96 inches) or the drain hose is inserted too far, siphoning and drainage issues occur.
- **Faulty Drain Pump:** The pump motor may be burned out, have a broken impeller, or be stuck due to foreign objects.
- **Blocked Home**

**Plumbing:** A clog in the household drain line or a full septic system can prevent water from leaving the washer.

- **Control Board Malfunction:** Rarely, the electronic control board misreads the water level or timing, triggering a false error.

Identifying the exact cause requires a methodical approach. We will now detail each troubleshooting step.

---

## **DIAGNOSING THE F21 ERROR: STEP-BY-STEP TROUBLESHOOTING**

---

Before you begin, unplug the washer from the electrical

outlet for safety. Also, have a bucket, towels, and a flashlight handy. Follow these steps in order, as they progress from simplest and most common fixes to more complex ones.

# Step 1: Check the Drain Hose and Standpipe

Start with the easiest potential issue. Examine the drain hose that runs from the back of the washer to the drain pipe or utility sink.

- Ensure the hose is not kinked or

tightly bent.  
Straighten any  
twists.

- If the hose is connected to a standpipe, make sure the pipe is not clogged. Pour a bucket of water down the standpipe; if it drains slowly, the house plumbing may be blocked.
- The drain hose should be inserted no more than 4 to 8 inches into the standpipe. If it is too deep, it can cause siphoning and drainage problems.
- Check that the standpipe height is between 30 and 96 inches (most codes require 36–42 inches). If it is too high, the

pump cannot  
overcome the  
vertical lift.

## Step 2: Clean the Drain Pump Filter

On many **Maytag 3000 Series Washer** models, the drain pump filter is located behind a small access panel at the front bottom of the machine. This is a common area for debris to collect.

1. Unplug the washer.
2. Open the access panel (usually a small door or a removable lower kickplate).

3. Place a shallow pan or towels under the filter area to catch water.
4. Slowly twist the filter knob counterclockwise to release it (some models have a cap that pulls out). Be prepared for water to spill.
5. Remove the filter and clean it thoroughly under running water. Remove any lint, coins, hair, or small objects.
6. Check the cavity behind the filter for obstructions.
7. Reinstall the filter, ensuring it is tight but not over-tightened. Close the access panel.

## Step 3: Inspect the Drain Pump and Impeller

If the filter is clean and the hose is fine, the pump itself may be the problem.

- With the power off, disconnect the drain hose from the pump outlet and check for blockages inside the pump housing.
- You can often access the pump by removing the bottom panel or tilting the washer

carefully. Refer to your user manual for exact locations.

- Look for foreign objects like socks or bra wires that could prevent the impeller from spinning.
- If the pump motor is humming but not pumping, the impeller may be broken. In that case, the pump assembly will need replacement.

## Step 4: Check the

# Pressure Switch and Wiring

The pressure switch (also called a water level sensor) tells the control board when the drum is empty. A faulty switch can cause the F21 error.

1. Locate the pressure switch: usually a round plastic component on the upper side of the washer, connected to a small tube that runs down to the tub.
2. Check that the tube is not clogged, kinked, or disconnected.

If the tube is blocked, the switch may not detect the correct water level.

3. Inspect the wiring harness connecting the switch to the control board. Look for loose connectors, burnt wires, or corrosion.

## Step 5: Reset the Washer and Test

After performing the above checks, plug the washer back in and try a simple drain/spin cycle to see if the error clears. Sometimes a temporary glitch can

cause the F21 code, and a reset helps. To reset a **Maytag 3000 Series Washer**, unplug it for one minute, then plug it back in. If the error persists after resetting, the problem is likely mechanical or electrical.

---

### WHEN TO CALL A PROFESSIONAL FOR THE MAYTAG 3000 SERIES WASHER F 21 ERROR

---

While many homeowners can resolve the **Maytag 3000 Series Washer F 21** code themselves, some situations warrant a technician's expertise. Consider professional service if:

- You have cleaned the filter, checked the hose, and

examined the pump, but the error still appears.

- The drain pump does not run at all or makes unusual grinding noises.
- You suspect a control board failure—such as other error codes appearing simultaneously or the display acting erratically.
- There is a persistent electrical issue, like tripping the circuit breaker when the washer attempts to drain.
- Your home's plumbing has a recurring clog that requires a plumber to clear the main drain line.

Attempting complex repairs without proper knowledge can damage the washer or void the warranty. A qualified technician can use diagnostic tools to pinpoint the exact fault.

---

### **PREVENTING THE MAYTAG 3000 SERIES WASHER F 21 ERROR IN THE FUTURE**

---

Once you have resolved the F21 error, take proactive steps to prevent it from returning. These maintenance tips will keep your **Maytag 3000 Series Washer** draining smoothly.

- **Clean the drain pump filter regularly:** Check and clean the filter every three to six months,

depending on usage. This is the #1 preventive measure.

- **Empty pockets before washing:** Coins, pens, and small items often end up in the pump filter. Use mesh laundry bags for delicate items.
- **Use the correct detergent:** High-efficiency (HE) detergent is essential. Excess suds can create drainage issues.
- **Avoid overloading the washer:** Overloading strains the pump and can cause poor drainage.
- **Run a cleaning cycle monthly:** Use a washing machine cleaner or a hot water

cycle with vinegar to break down residues in the drain system.

- **Inspect the drain hose periodically:** Ensure the hose is not kinked, and the connection at the standpipe remains free of lint buildup.

---

## UNDERSTANDING THE MAYTAG 3000 SERIES WASHER MODELS

---

The Maytag 3000 Series includes both front-load and top-load models. While the F21 error code has the same meaning across the series, the location of components like the pump filter varies. Always consult your specific model's manual. Common

models in this series include the **MVW6230HW**, **MVW6200KW**, and similar. The troubleshooting steps above are generally applicable to all, but note that top-load models may have the filter behind a lower front panel or inside the drum. For front-loaders, the filter is almost always behind the small bottom access door.

---

### **IS THE F21 ERROR COVERED UNDER WARRANTY?**

---

If your **Maytag 3000 Series Washer** is still under the original manufacturer's warranty (typically one year for parts and labor), the F21 error caused by defects in materials or workmanship should be covered. However,

blockages due to user error—such as leaving items in pockets or failing to clean the filter—are usually not covered. Check your warranty terms or contact Maytag support. If you purchased an extended service plan, it may also cover this type of repair.

---

### **FREQUENTLY ASKED QUESTIONS ABOUT THE MAYTAG 3000 SERIES WASHER F 21 ERROR**

---

## Can I still use my washer if

## the F21 code appears?

It is not recommended. The washer stops functioning to prevent damage. Continuing to run cycles could overheat the pump or cause water to back up. You must resolve the error before restarting.

Does the  
F21 error  
always  
mean a  
clogged

## pump?

No, but a clogged pump filter is the most common cause. Other possibilities include hose kinks, high standpipe, faulty pump, or pressure switch issues. Diagnose step by step.

How  
much  
does it  
cost to fix  
a Maytag  
3000  
Series

# F21 washer error?

If you fix it yourself (clearing a blockage), the cost is \$0. If you

need a new drain pump, parts range from \$30 to \$80, plus labor if you hire a technician, which can total \$150-\$300 depending on your area.

---

## CONCLUSION

---