

How To Update Gopro Hero 3

How To Update Gopro Hero 3

Downloaded from everybodystreet.com by Levy & Alexis

INTRODUCTION: BREATHE NEW LIFE INTO YOUR ACTION CAMERA

The GoPro Hero 3 series, including the White, Silver, and Black editions, forever changed the landscape of action cameras. Even years after its release, this rugged little device remains a favorite for adventurers, vloggers, and casual users who appreciate its compact design and impressive video quality. However, to keep your Hero 3 performing at its peak, you need to know **how to update GoPro Hero 3** firmware properly. A firmware update can unlock new features, improve stability, fix bugs, and enhance compatibility with modern memory cards and accessories. Whether you have just dusted off your old Hero 3 from a drawer or you are a new user exploring its capabilities, this guide will walk you through every step of the process. By the end, your camera will be running the latest software, ready to capture your next adventure with renewed reliability.

WHY UPDATING YOUR GOPRO HERO 3 STILL MATTERS

You might wonder why you should bother updating a camera that is no longer in production. The answer is simple: firmware updates are the lifeblood of any electronic device. For the GoPro Hero 3, the final official firmware releases addressed several critical issues that affect day-to-day use. These updates improved Wi-Fi connectivity, enhanced battery life management, and fixed glitches that could cause the camera to freeze or fail to record. Additionally, updating ensures compatibility with newer microSD cards, which often use different formatting standards than older models. Without the latest firmware, your Hero 3 might struggle to recognize high-capacity cards or deliver consistent write speeds. Knowing **how to update GoPro Hero 3** correctly means you can avoid these headaches and enjoy a smoother, more reliable shooting experience. It also prepares your camera to work seamlessly with the GoPro App, allowing you to control it remotely and preview shots on your smartphone.

WHAT YOU NEED BEFORE STARTING THE UPDATE

Before diving into the update process, gathering the right tools and understanding the prerequisites will save you time and frustration. The GoPro Hero 3 update is straightforward, but it requires careful attention to detail. Here is what you will need:

- **A fully charged battery:** The update process can take several minutes, and a dead battery midway through could brick your camera. Ensure your GoPro Hero 3 battery is charged to at least 80 percent.
- **A compatible microSD card:** The card must be formatted to FAT32. Cards larger than 32GB may require third-party formatting tools, as Windows and macOS do not natively offer FAT32 for larger capacities. For best results, use a 32GB or smaller card formatted directly in the camera.
- **A computer with internet access:** You will need to download the firmware file from the official GoPro support website. Both Windows and Mac computers work fine for this task.
- **A microSD card reader or a direct USB connection:** You need to copy the firmware file onto the SD card. Most computers have built-in card readers, but you can also connect the camera via USB in mass storage mode.
- **Patience and a stable environment:** Avoid interruptions. Find a quiet space where you can focus on the steps without rushing.

Once you have assembled these items, you are ready to proceed. Knowing **how to update GoPro Hero 3** begins with proper preparation, so do not skip this step.

STEP-BY-STEP GUIDE: HOW TO UPDATE GOPRO HERO 3

Now, let us walk through the entire update process. Follow each step carefully to ensure a successful firmware installation. This method works for the Hero 3 White, Hero 3 Silver, and Hero 3 Black editions.

Step 1: Identify Your Current Firmware Version

Before you update, it is helpful to know which firmware version your camera is currently running. This allows you to confirm that the update was applied correctly afterward. To check your firmware:

1. Turn on your GoPro Hero 3.
2. Press the Mode button until you reach the Setup menu (wrench icon).
3. Navigate to the "About" section using the Shutter button.
4. Press the Shutter button to select it. The current firmware version will be displayed on the screen.

Write down this number. The latest official firmware for the Hero 3 series is version HD3.11.03.01 for the Black edition, with similar versions for the Silver and White models. If you already have this version, no update is needed. Otherwise, proceed.

Step 2: Download the Correct Firmware File

The most critical part of learning **how to update GoPro Hero 3** is obtaining the correct firmware file. GoPro provides these files on their official support page. Here is how to get it:

1. Visit the GoPro support website (support.gopro.com).
2. Navigate to the "Downloads" or "Software & Firmware" section.
3. Search for "HERO3" or "HERO3 Black" depending on your model.
4. Locate the latest firmware update file. It will be a .zip archive.
5. Download the file to your computer. Do not rename or modify the file.

Be cautious of third-party websites offering firmware downloads. Always use the official GoPro source to avoid corrupted files or malware. The file name typically follows a pattern like "HERO3_Black_FW_Update.zip."

Step 3: Prepare Your microSD Card

For the update to work, the microSD card must be empty (or at least not contain any other firmware files) and formatted to FAT32. Here is the best way to prepare it:

1. Insert the microSD card into your camera.
2. Turn on the camera.
3. Navigate to the Setup menu and select "Format" to format the card directly in the camera. This ensures the correct file system.
4. Alternatively, you can format the card on your computer using a FAT32 formatting tool. For cards under 32GB, the built-in Windows or Mac formatter works fine.
5. After formatting, remove the card and insert it into your computer's card reader.

If you are using a card larger than 32GB, you may need a free tool like "GUIFormat" or "Rufus" to force FAT32 formatting. However, for best compatibility with the Hero 3, a 32GB card is recommended.

Step 4: Copy the Firmware to the SD Card

Now, you will transfer the firmware file to your microSD card. This step must be done exactly right for the camera to recognize the update.

1. Extract the downloaded .zip file on your computer. You should see a file named something like "UPDATE.zip" or "fwupdate.bin" inside.
2. Do not extract the contents of the extracted file further. The camera expects a specific file structure.
3. Copy the entire extracted folder or the individual firmware file (depending on the instructions in the readme) to the root directory of your microSD card.
4. Eject the SD card safely from your computer using the "Safely Remove Hardware" option.

Important: The firmware file must be placed directly on the card, not inside any subfolders. If the instruction says to place the "UPDATE.zip" file, do exactly that. Some versions require the .bin file. Always read the included readme.txt for model-specific instructions. Mastering **how to update GoPro Hero 3** means following these details precisely.

Step 5: Install the Firmware on Your GoPro Hero 3

With the firmware file on the SD card, it is time to install it on the camera. This process takes about two to three minutes, during which you must not interrupt the camera.

1. Insert the microSD card with the firmware file into your GoPro Hero 3.
2. Turn on the camera. You should see a message on the screen indicating that a firmware update is detected. The camera may prompt you to proceed.
3. Press the Shutter button to start the update. The camera screen may go dark, but the LED lights will blink or stay solid to indicate activity.
4. Wait patiently. Do not press any buttons, remove the battery, or turn off the camera during the update.
5. After two to five minutes, the camera will either restart automatically or display a "Update Complete" message on the screen.

If the camera does not recognize the update file, double-check that the file is in the correct location and that the SD card is formatted properly. You may need to try a different card or re-download the firmware.

Step 6: Verify the Update Was Successful

Once your GoPro Hero 3 restarts, you should confirm that the new firmware is installed. Follow the same steps as in Step 1 to check the version number. If it matches the latest official release, congratulations! You have successfully completed the update. If the version number remains unchanged, repeat the process from Step 3, ensuring you formatted the card and copied the file correctly. Knowing **how to update GoPro Hero 3** includes verifying the outcome to ensure everything worked.

COMMON UPDATE ISSUES AND HOW TO FIX THEM

Even when following every step, you might encounter a few hiccups. Here are the most common problems users face when updating their GoPro Hero 3 and how to resolve them.

The Camera Does Not Detect the Update File

This is the most frequent issue. Usually, it happens because the firmware file is in the wrong location or the SD card is not formatted correctly. Ensure the file is on the root directory of the card, not inside any folder. Also, confirm that the card is formatted as FAT32. If you are using a card larger than 32GB, try a smaller one. Some Hero 3 models are picky about card brands; SanDisk and Lexar typically work best.

The Update Freezes or Stops Midway

If the camera freezes during the update, your battery may have died or the firmware file may be corrupted. Remove the battery, reinsert it, and start over with a freshly formatted card and a freshly downloaded firmware file. Always keep your battery fully charged before attempting the update.

The Camera Turns On but Shows No Video Output

After a successful update, some users report that the camera works fine but the video output to a TV or monitor is missing. This is usually a settings issue. Go to the Setup menu and check the "Video Out" setting. Ensure it is set to NTSC or PAL depending on your region. The update may have reset this setting to default.

Wi-Fi Connectivity Problems After Update

If your GoPro Hero 3 experiences Wi-Fi issues after the update, try resetting the Wi-Fi settings. Go to the Setup menu, find "Reset Wi-Fi," and confirm. Then, reconnect your camera to the GoPro App. This often resolves pairing and connection drops.

TIPS FOR GETTING THE MOST OUT OF YOUR UPDATED GOPRO HERO 3

Now that your firmware is up to date, here are a few practical tips to maximize your camera's performance:

- **Use high-quality microSD cards:** The Hero 3 is older hardware, and high-speed cards can cause issues. Stick to Class 10 or UHS-I cards from reputable brands. Avoid counterfeit cards.
- **Format your card in the camera regularly:** This reduces file fragmentation and ensures consistent recording performance. Make it a habit before every big shoot.
- **Calibrate your battery:** If you notice battery drain after the update, fully charge the battery, then let the camera run until it dies completely. Then, charge it again. This recalibrates the battery gauge.
- **Explore the updated settings:** The firmware update may have added new features or changed the menu layout. Take time to browse through all settings to discover options you might have missed.