
How To Make Soy Candle Wax

*How To Make Soy
Candle Wax*

*Downloaded from
everybodystreet.com by
Shelton & Townsend*

UNDERSTANDING THE ART OF MAKING SOY CANDLE WAX

Creating your own candles at home has become a beloved craft for many, offering a sense of accomplishment and the ability to tailor scents and aesthetics to personal preference. At the heart of this rewarding hobby lies the foundational skill of working with the primary material itself. This guide will walk you through the entire process,

from selecting the right ingredients to pouring a perfect, clean-burning candle. While the phrase "how to make soy candle wax" might suggest creating the wax from raw soybeans, the practical reality for home crafters involves transforming commercially available soy wax flakes into a beautifully finished candle. This article will demystify the entire process, equipping you with the knowledge to craft candles that burn evenly, smell wonderful, and look professional.

Soy wax, derived from soybean oil, has

surged in popularity as a natural, renewable, and biodegradable alternative to traditional paraffin wax. Its slow burn, excellent scent throw, and easy cleanup with soap and water make it a favorite among beginners and experienced chandlers alike. Before you begin, it is crucial to understand that making soy candles involves a straightforward yet precise process. Success hinges on proper temperature management, accurate measurements, and a bit of patience. This comprehensive guide will cover everything you need to know, ensuring that your first batch of candles is a resounding success.

WHAT YOU NEED TO GET

STARTED

Before diving into the step-by-step process of how to make soy candle wax into a finished product, you must gather the essential tools and ingredients. Having everything prepared beforehand ensures a smooth and safe candle-making experience.

Essential Ingredients

- **Soy Wax Flakes:** The star of the show. Look for a high-quality, natural soy wax that is specifically designed for candle making. These flakes are often labeled as "container wax" or "pillar wax."

- **Candle Wicks:** Choose the correct wick size for your container. A wick that is too small will create a weak flame and a melt pool that doesn't reach the edges, causing tunneling. A wick that is too large will produce a high, sooty flame and a dangerously hot container.
- **Fragrance Oil (Optional):** Use oils specifically formulated for candle making. These are designed to bind with the wax at specific temperatures and ensure a strong, lasting scent.
- **Wick Tabs or Sustainers:** Small metal discs that attach to the bottom of the wick to keep it centered and anchored at the bottom of the container.

Essential Equipment

- **Double Boiler or Melting Pot:** A double boiler is the safest way to melt wax. You can use a dedicated wax melting pitcher or a large heat-safe glass measuring cup placed in a pot of simmering water. Never melt wax directly on a heat source.
- **Thermometer:** A candy or infrared thermometer is crucial for monitoring the wax temperature. Precision is key for melting and fragrance addition.
- **Scale:** A digital kitchen scale is necessary for measuring wax and

fragrance oil by weight, which is much more accurate than using volume.

- **Heat Source:** A stove or electric hot plate.
- **Containers:** Glass jars, tins, or ceramic vessels that are heat-safe and wide enough to allow for a good melt pool.
- **Stirring Utensils:** A dedicated stainless steel spoon or silicone spatula.
- **Wick Centering Tool:** A device to hold the wick upright while the wax cools. You can use a pencil, chopstick, or a dedicated centering tool.
- **Safety Gear:** An apron, oven mitts, and goggles to protect from hot wax.

THE STEP-BY-STEP PROCESS OF MAKING SOY CANDLES

Now that you have your supplies ready, let's explore the detailed process of how to make soy candle wax into a beautiful, functional candle. Read through all the steps before you begin to ensure a seamless workflow.

Step 1: Prepare Your Workspace and Containers

Start by thoroughly cleaning your candle containers with hot, soapy water. Any dust, oil, or residue can interfere with

the wax adhesion and cause imperfections. Dry them completely. Place your containers on a level surface or a tray. Use a glue dot or a dab of hot glue to attach a wick tab to the bottom center of each container. Make sure the wick is straight and standing tall. Use a wick centering tool or a pencil laid across the top of the container to hold the wick in place.

Step 2: Measure and Melt the Soy Wax

Using your digital scale, weigh out the amount of soy wax flakes you need. A

good rule of thumb is to fill your container with water, pour that water into a measuring cup to find the volume, and then multiply that volume (in fluid ounces) by 0.86 to get the weight of wax needed in ounces. For example, a 10-ounce jar will need about 8.6 ounces of wax. Place the wax flakes into your melting pot or double boiler. Heat the water in the bottom pot to a gentle simmer. Never let the water boil vigorously, as this can cause the wax to overheat. Stir the wax gently and occasionally as it melts. Use your thermometer to monitor the temperature. Most soy waxes have a recommended melting temperature range, typically between 170°F and 185°F (77°C to 85°C). Do not exceed 200°F (93°C) as it can degrade the wax

and affect its burning properties.

Step 3: Add Fragrance Oil at the Correct Temperature

Once the wax has completely melted, remove it from the heat source. Allow it to cool slightly. The optimal temperature for adding fragrance oil is usually between 160°F and 175°F (71°C to 80°C). Adding fragrance oil when the wax is too hot can cause the scent to "burn off," reducing the throw. Adding it when the wax is too cool can lead to

poor binding and a weak scent. Measure your fragrance oil on the scale. The general recommendation is to use 6% to 10% fragrance oil per weight of wax. For beginners, 6% (1 ounce of fragrance per 16 ounces of wax) is a safe starting point. Pour the fragrance oil into the melted wax slowly while stirring gently but thoroughly. Stir for 2-3 minutes to ensure the oil is fully incorporated. Overstirring can introduce air bubbles, so aim for a steady, even mix.

Step 4: The Pouring Phase

Allow the scented wax to cool to the proper pouring temperature. This is a critical step in the process of how to

make soy candle wax perform well. The ideal pouring temperature for soy wax is generally between 130°F and 145°F (54°C to 63°C). Pouring at the correct temperature helps prevent common issues like sinkholes, frosting, and poor adhesion to the container. Slowly and carefully pour the wax into your prepared containers. Fill them to your desired level, leaving about a half-inch of headspace at the top. Pouring slowly helps minimize air bubbles. Be careful not to pour the wax directly onto the wick, as this can displace it.

Step 5: Allow the

Candles to Cool and Set

Place your freshly poured candles in a cool, draft-free area where they can cool and set undisturbed for at least 24 hours. Avoid moving them or jostling them during this time. Drafts and temperature fluctuations can cause surface imperfections, such as cracks or "frosting" (a crystalline, white appearance). As the wax cools, it will contract. This can sometimes create a small sinkhole around the wick. This is normal. You might notice a small depression form as the wax solidifies. This is a perfect opportunity to perform a "second pour."

Step 6: The Second Pour (Optional but Recommended)

After the candles have fully set, inspect the surface. If you see a sinkhole or a rough top, you can do a second pour. Save a small amount of the original melted wax in your melting pot. Re-melt it gently and allow it to cool back down to about 155°F to 165°F (68°C to 74°C). Gently pour this small amount of wax over the top of the candle to create a smooth, level surface. This step is a

hallmark of professional candle making and ensures a beautiful, polished final look.

TROUBLESHOOTING COMMON ISSUES

Even with the best instructions, you may encounter a few challenges as you learn how to make soy candle wax perform perfectly. Here are some common problems and their solutions.

Frosting

Frosting appears as a white, crystalline pattern on the surface of the candle. It is a natural characteristic of soy wax and does not affect the candle's performance. To minimize frosting, you can pour the wax at a slightly lower

temperature (around 120°F to 125°F) and ensure your workspace is a consistent temperature. Some candle makers embrace frosting as part of the rustic, natural aesthetic of soy wax.

Tunneling

Tunneling occurs when the candle burns down the middle, leaving a thick wall of unmelted wax around the edges. This is often caused by a wick that is too small or by not allowing the candle to achieve a full melting pool during the first burn. Always burn your soy candle long enough for the wax pool to reach the edges of the container. This first burn is crucial for "memory" and will set the stage for even burning in the future.

Poor Scent Throw

A weak scent, either while the candle is cold or while it is burning, can be frustrating. Several factors can contribute to this. First, ensure you are using a fragrance oil specifically designed for candles and at the correct ratio (6-10%). Second, ensure you added the fragrance oil at the right temperature (160-175°F) and stirred it thoroughly. Third, allow the candle to cure for at least 48 hours, though a longer cure time of 1-2 weeks often produces a stronger scent throw.

Cracks and Sinkholes

Surface cracks and sinkholes are usually caused by pouring the wax too hot or cooling the candles too quickly. To prevent this, ensure you pour at the recommended temperature (130-145°F) and let the candles cool slowly in a stable, draft-free environment. A second pour, as described above, is the best way to fix a rough surface.

TIPS FOR SUCCESS IN SOY CANDLE MAKING

As you master the basics of how to make soy candle wax into a finished product, keep these expert tips in mind. Your first

batch might not be perfect, but each attempt will teach you something new.

- **Always use a scale:** Measuring by weight is far more accurate than using measuring cups for both wax and fragrance oil.
- **Keep detailed notes:** Record the exact wax type, fragrance oil brand, percentages, temperatures, and wick sizes for each batch. This helps you replicate successes and troubleshoot failures.
- **Patience is a virtue:** Allow your candles to cure for at least 48 hours before burning. A longer cure time of 1-2 weeks will significantly improve the scent throw.
- **Safety first:** Never leave melting

wax unattended. Keep a fire extinguisher or a lid nearby to smother a grease fire. Melted wax is flammable, so treat it with respect.

- **Test, test, test:** Before making a large batch, always test a single candle. Burn it in a controlled environment to evaluate the melt pool, flame height, and scent throw.
- **Clean your equipment:** Soy wax is easy to clean with hot, soapy water. Clean your pots and utensils while the wax is still warm and liquid.

CONCLUSION

Learning how to make soy candle wax into a beautiful, functional candle is a

journey that blends science, art, and a deep appreciation for natural materials. From choosing the right wax and wick to mastering the crucial temperatures of melting, scenting, and pouring, each step contributes to the final product. While the process is straightforward, it rewards attention to detail and a willingness to learn from each pour. The satisfaction of lighting a candle you made with your own hands, knowing exactly what is in it, is a joy worth cultivating. With the knowledge from this guide, you are now well-equipped to begin your candle-making adventure. Embrace the process, experiment with scents and containers, and enjoy the warm, natural glow of your handcrafted soy candles. The world of candle making is open to you, and your first perfect

burn is just a pour away.