
How To Open A Master Lock

*How To Open A Master
Lock*

*Downloaded from
everybodystreet.com by
Taylor & Eva*

INTRODUCTION: WHEN YOU NEED TO KNOW HOW TO OPEN A MASTER LOCK

Few things are as frustrating as standing in front of a locked locker, gate, or storage unit with the vague memory that you *did* set a combination, but now the numbers have completely escaped you. Master Lock is one of the most trusted names in security, and their combination padlocks, keyed padlocks, and lock

boxes are used everywhere from high school gymnasiums to commercial job sites. But even the best locks can leave you locked out when you forget a code, lose a key, or encounter a stuck mechanism.

Knowing **how to open a Master Lock** is a practical skill that can save you time, money, and a great deal of hassle. In this guide, we will walk through the legitimate, non-destructive methods for opening the most common types of Master Locks. Whether you have a standard 3-digit combination lock, a

speed dial lock, or a keyed padlock, these step-by-step instructions are designed to help you regain access without calling a locksmith. We will also cover troubleshooting for sticky dials, forgotten codes, and seized mechanisms. Let us begin with the basics.

UNDERSTANDING THE DIFFERENT TYPES OF MASTER LOCKS

Before diving into specific opening techniques, it is important to identify which type of Master Lock you are dealing with. The method you use will depend entirely on the lock style.

- **Standard Combination Padlocks (e.g., Model 1500D, 175, 200):** These feature a

numbered dial that you rotate right, left, and right to align internal gates. They are the classic gym locker lock.

- **Speed Dial or Set-Your-Own Combination Locks (e.g., 1635, 1630):** These use a dial that turns in one direction only, making them faster to open.
- **Keyed Padlocks (e.g., Magnum, Pro Series):** These require a physical key. If the key is lost, opening them is different from a combination lock.
- **Combination Lock Boxes (e.g., 5400D, 5420D):** Used for real estate lock boxes or securing keys. They have a similar dial mechanism to padlocks but with a different body style.

- **Electronic or Bluetooth Locks (e.g., 4400DLH, 4410DBL):**

These are modern, app-controlled locks. Opening them may involve a reset or battery change.

Identifying your lock type is the first step. For this article, we will focus primarily on the most common mechanical combination and keyed padlocks, as these are the ones people most frequently need help with.

HOW TO OPEN A STANDARD MASTER LOCK COMBINATION PADLOCK

The standard combination padlock is a classic. If you have forgotten the combination, you cannot simply "hack" it quickly without damage, but you can use

a systematic technique if you know the lock is set to its factory default or if you have a few clues. The standard method for opening a known combination is straightforward. If the combination is 10-20-30, for example, here is the proper procedure.

The Correct Dialing Sequence for a Known Combination

1. **Start with the dial at 0.** Ensure the shackle is in the locked position (pushed down).

2. **Turn right (clockwise) to the first number.** Rotate the dial to the right, passing the first number three times. On the fourth turn, stop on the first number. For example, for combination 10-20-30, turn right until you land on 10 for the fourth time.
3. **Turn left (counter-clockwise) to the second number.** Rotate the dial to the left, passing the second number twice. On the third turn, stop on the second number. So, pass 20 twice, then land on it the third time.
4. **Turn right (clockwise) to the third number.** This time, simply turn the dial to the right until you reach the third number on your first approach. Do not pass it.

5. **Pull the shackle.** If the combination is correct, the shackle will release.

This process can be tricky if you are not precise. **Common mistakes** include not counting the rotations correctly or turning the dial too fast. Slow, deliberate movements are key.

What to Do If You Forgot the Combination

If you have forgotten the combination, do not panic. There are a few legitimate ways to proceed without destroying the lock.

- **Check the serial number.**

Master Lock often records combinations for their locks. If you have the serial number (usually engraved on the back or bottom of the lock), you can visit the Master Lock website or call their customer service. For a fee, they may be able to provide the combination. This only works if the lock has not been reset from its factory default.

- **Try default combinations.** Many school or gym locks are set to a default combination like 0-0-0, 1-2-3, or 10-20-30. If you have never changed the combination, these are worth trying first.

- **Use the "stethoscope" or "feel" method (for advanced users).**

This is a non-destructive technique

where you apply slight tension to the shackle and slowly rotate the dial, feeling for a slight "click" or resistance at each number. This takes practice and patience, but it is a known method for opening combination locks without the code. It works by exploiting the internal tolerances of the lock.

HOW TO OPEN A MASTER LOCK SPEED DIAL COMBINATION LOCK

Speed Dial locks, such as the popular Master Lock 1635, are designed for quick access. They use a different mechanism than standard dials. Instead of rotating left and right, you turn the dial in one direction only.

Opening a Speed Dial Lock with a Known Combination

1. **Turn the dial to the right (clockwise) until you hit the first number.** Stop there. Do not pass it.
2. **Turn the dial to the left (counter-clockwise) until you hit the second number.** Stop there.
3. **Turn the dial back to the right until you hit the third number.**

Stop there.

4. **Pull the shackle.** The lock should open.

The key difference here is that you do not have to pass the numbers multiple times. It is a straight, one-turn-per-number sequence. If you have reset the combination yourself and forgotten it, the same factory reset options apply. Check the back of the lock for a serial number or a reset code.

HOW TO OPEN A MASTER KEYED PADLOCK WITHOUT A KEY

Losing the key to a padlock is a different problem. For keyed locks, the methods are more physical.

Non-Destructive Methods for Keyed Locks

- **Use a bolt cutter.** This is the fastest and most common method for cutting through a padlock shackle. Master Lock shackles vary in thickness. A 24-inch bolt cutter will handle most standard padlocks. This destroys the lock but is quick.
- **Use a shim.** A shim is a thin piece of metal (often from a soda can) that you slide between the shackle and the locking mechanism. This

works best on cheap or worn locks. Master Locks are often designed to resist shimming, but it is worth a try on older models.

- **Call a locksmith.** A professional can pick the lock or drill it in a way that preserves the lock body. This is the safest option if you want to reuse the lock or if the padlock secures something valuable.
- **Use a key extractor.** If you have a broken key stuck in the lock, a key extractor tool can remove the broken piece. Do not try to force the lock with pliers, as this can damage the internal pins.

Destructive Methods (Last Resort)

- **Drilling.** Drilling into the lock cylinder or the pins can destroy the internal mechanism, allowing the shackle to release. This requires a power drill and a steady hand. It is messy and permanent.
- **Sawing the shackle.** A hacksaw can cut through a shackle, but it is time-consuming and noisy. Hardened steel shackles will dull blades quickly.

Important Warning: Never attempt to

use lock picking tools on a lock that does not belong to you. This guide is intended for opening your own locks when you have lost access. Using these techniques on a lock you do not own is illegal in most jurisdictions.

HOW TO OPEN A MASTER LOCK BOX (E.G., 5400D)

Lock boxes used for real estate or key storage operate similarly to combination padlocks but have a larger dial and a push-button release.

Opening a Lock

Box with a Known Combination

1. **Turn the dial to the right (clockwise) to the first number, passing it four times.** Stop on the first number the fifth time.
2. **Turn the dial to the left (counter-clockwise) to the second number, passing it three times.** Stop on the second number the fourth time.
3. **Turn the dial to the right to the third number, passing it**

twice. Stop on the third number the third time.

4. **Turn the dial left to the fourth number, passing it once.** Stop on the fourth number the second time.
5. **Turn the dial right back to 0.**
6. **Press the release button.** The lock box door will pop open.

This process is more complex due to the four-number combination and the multiple passes. It is crucial to count carefully. If the lock box is locked and you do not know the code, check with your real estate agent or property manager. There is no quick non-destructive way to open these without the code, other than drilling the dial plate.

TROUBLESHOOTING COMMON ISSUES

Sometimes the issue is not a forgotten combination, but a mechanical problem. Here are some common issues and how to fix them.

Sticky or Hard-to-Turn Dial

If the dial feels gritty or sticks, the lock may be dirty or in need of lubrication. **Never use oil-based lubricants** like WD-40 for this, as they can attract dust and gum up the mechanism over time. Instead, use a graphite powder lubricant. Apply a small amount into the dial gap and turn the dial several times to work it

in. This is usually enough to free up a sticky dial.

Shackle Won't Open Even with Correct Combination

This is often a sign of internal misalignment or a broken part. Try the following:

- **Apply light upward pressure** on the shackle while turning the dial.
- **Tap the lock body gently** with a rubber mallet. Sometimes the pins

jar loose.

- **Try the combination again very slowly.** Ensure you are stopping exactly on the numbers, not between them.

If none of this works, the internal mechanism may be broken. The lock will likely need to be cut off or replaced.

Reset Combination Not Working

Many Master Locks allow you to set your own combination using a reset tool or a specific sequence. If you try to reset the

lock and the combination is not accepted, you may have performed the reset incorrectly. Refer to the specific manual for your model online. Common errors include not having the shackle in the correct position (usually open) or not pressing the reset button firmly enough.

PREVENTIVE TIPS TO AVOID FUTURE LOCKOUTS

Once you have successfully opened your Master Lock, take steps to avoid this situation again.

- **Write down the combination** and store it in a secure place (e.g., a password manager or a locked drawer at home). Do not store it in your phone notes as "lock