

---

# 2000 Mercury Grand Marquis Fuse Box Diagram

---

*2000 Mercury Grand  
Marquis Fuse Box  
Diagram*

*Downloaded from  
[everybodystreet.com](http://everybodystreet.com) by  
Clark & Clark*

---

## **UNDER THE HOOD AND BEHIND THE GLOVE BOX: YOUR GUIDE TO THE 2000 MERCURY GRAND MARQUIS FUSE BOX DIAGRAM**

---

Owning a 2000 Mercury Grand Marquis often means appreciating a blend of classic American comfort and straightforward engineering. However, even the most reliable vehicles can

encounter electrical gremlins. When a power window stops responding, the interior lights refuse to illuminate, or the radio goes silent, the first place to check is the fuse box. Understanding the **2000 Mercury Grand Marquis fuse box diagram** is not just about knowing where fuses are located; it is about empowering yourself to perform quick diagnostics and get back on the road without an unnecessary trip to the mechanic. This guide will walk you

through everything you need to know, from the physical locations of the fuse panels to the specific functions of each fuse and relay.

Whether you are a seasoned DIY enthusiast or a new owner of this full-size sedan, having a clear roadmap to your vehicle's electrical system is invaluable. We will decode the diagrams, explain common issues, and provide practical tips for fuse replacement. By the end of this article, you will have a thorough understanding of how to read and utilize your Grand Marquis fuse panel layouts.

## Where Are the Fuse Boxes Located?

Before diving into the specifics of the diagram, you must first locate the fuse panels. The 2000 Mercury Grand Marquis houses two primary fuse boxes:

- **The Interior Fuse Panel (Passenger Compartment):** This panel is located under the dashboard, to the left of the steering wheel. In most models, it is hidden behind a small, rectangular access panel that you can simply pull off with your

hands. You may need to sit in the driver's seat and look under the dash to find it. This panel controls most of the vehicle's interior components, such as the instrument cluster, the blower motor, the power locks, and the turn signals.

- **The Power Distribution Box (Under the Hood):** This larger box is located in the engine compartment, typically near the battery on the driver's side (front, left corner of the engine bay). It is a black plastic box with a hard snap-on lid. This box houses the high-amperage fuses and relays for major engine and chassis systems, including the engine control module (ECM), the cooling

fan, the anti-lock brake system (ABS), and the horn.

Knowing these two locations is the first critical step. Once you have accessed the correct panel, you will need the **2000 Mercury Grand Marquis fuse box diagram** printed on the lid or in your owner's manual to identify the specific fuse or relay in question.

## Decoding the Interior Fuse Panel Diagram

The interior fuse panel, also known as the central junction box (CJB), contains mini and low-profile fuses. The diagram

is typically printed on the back of the access panel you removed. If the printing is faded or missing, you can find a clear version in the vehicle's owner's manual. Here is a breakdown of common circuits found in this panel:

### KEY CIRCUITS IN THE PASSENGER COMPARTMENT PANEL

- **Cigar Lighter / Power Point:**

This is often one of the most frequently blown fuses. In the 2000 Grand Marquis, it is usually a 15A or 20A fuse. If your 12V accessory port or cigarette lighter is not working, start here.

- **Power Windows and Locks:** The Grand Marquis typically uses a circuit breaker for the power

windows and a separate fuse for the power door locks. If none of the windows work, the circuit breaker may have tripped. If only one window is inoperative, the issue is likely the switch or motor, not the fuse.

- **Instrument Cluster:** A blown fuse here will lead to a dead speedometer, odometer, or fuel gauge. Check the 10A fuse labeled "CLUSTER" or "INST" if your gauges are not functioning.
- **Turn Signals and Brake Lights:** These circuits are usually separate. If your turn signals work but your brake lights do not, or vice versa, specific fuses protect each system.
- **Radio and Amplifier:** The audio

system is typically protected by a 15A or 20A fuse. If your radio has power but no sound, or is completely dead, this is a prime suspect.

It is crucial to note that the exact fuse assignments can vary slightly based on the trim level (GS, LS) and optional equipment (such as the JBL audio system or adjustable pedals). Always refer to the specific diagram on your access panel for your vehicle.

## Understanding the Under-Hood

## Power Distribution Box

The under-hood fuse box, often called the battery junction box (BJB), handles higher current loads. Opening this box reveals a densely packed array of large fuses, known as maxi fuses, and a series of relays. The **2000 Mercury Grand Marquis fuse box diagram** for this box is usually printed on the underside of the lid. Because of the higher currents involved, safety is paramount when working here.

### MAIN COMPONENTS AND THEIR

## FUNCTIONS

- **Cooling Fan Relay and Fuse:** A failure in this area can lead to engine overheating. If your electric cooling fan is not spinning when the engine is hot, check the 30A or 40A fuse and the associated relay in this box.
- **Anti-Lock Brake System (ABS):** The ABS module is protected by a high-amperage fuse (often 40A or 50A). If your ABS light is illuminated and the system is not functioning, a failed fuse is a possible cause, though a faulty sensor is more common.
- **Powertrain Control Module (PCM) Relay:** This relay provides power to the engine computer. If it

fails, the engine may crank but not start.

- **Horn Relay and Fuse:** A non-functioning horn is often due to a blown fuse or a failed relay, both easily tested and replaced in this box.
- **Main Fuse Links:** These are very large fuses (60A, 80A, or 100A) that protect the entire vehicle's electrical system from a major short circuit. These seldom blow, but if they do, it indicates a serious electrical problem that needs professional attention.

When replacing a fuse in the power distribution box, always use the exact amperage specified in the **2000 Mercury Grand Marquis fuse box**

**diagram.** Using a higher amperage fuse can melt wiring and cause a fire.

# Common Electrical Problems and Troubleshooting Tips

Even with a diagram in hand, diagnosing an electrical issue can be frustrating. Here are some common complaints for the 2000 Grand Marquis and how to use the fuse box diagram to track them down:

## **SCENARIO 1: THE INTERIOR LIGHTS AND DOME LIGHT ARE OUT**

This is often a simple fix. Locate the fuse labeled "DOME" or "INT LIGHT" on the interior panel. It is typically a 15A fuse. If the fuse is blown, replace it. However, if it blows again immediately, you likely have a short circuit in a door jamb switch or a courtesy light fixture.

## **SCENARIO 2: THE BLOWER MOTOR (HEATER/A/C FAN) STOPPED WORKING**

The blower motor is a common failure point. First, check the blower motor fuse in the interior panel (usually 30A or 40A). If the fuse is good, the issue could be the blower motor resistor or the motor itself. The fuse protects the circuit; if the motor

siezes, it can draw excessive current and blow the fuse.

### SCENARIO 3: THE CAR CRANKS BUT WON'T START

Before assuming a bad fuel pump or ignition system, check the under-hood power distribution box. Look for the PCM relay and the fuel pump relay. Swap them with a similar relay (like the horn relay) to see if the car starts. Also, inspect the fuse for the PCM and the fuel injectors.

## How to Read the

## Diagram Like a Pro

The diagram itself can look like a complex blueprint, but it follows a logical pattern. Here is how to interpret it:

1. **Fuse Number or Label:** Each slot is numbered or labeled with a short abbreviation (e.g., F1.1 or "LAMP").
2. **Amperage Rating:** The diagram will clearly state the amperage (A) for each fuse, such as 10A, 15A, or 20A.
3. **Circuit Name:** This describes what the fuse protects (e.g., "Stop Lamps," "Power Seat," "Engine

Control").

4. **Color Coding:** Fuses are color-coded by amperage. For example, a 10A fuse is red, a 15A is blue, and a 20A is yellow. The diagram often uses these colors as a visual reference.
5. **Relays:** These are larger square components. The diagram will label what each relay controls (e.g., "A/C Clutch Relay," "Starter Relay").

Using the **2000 Mercury Grand Marquis fuse box diagram** is a process of matching the physical layout of the panel to the map provided. A common mistake is reading the diagram upside down. Most diagrams are oriented as if you are looking directly at

the face of the fuse panel, so line them up carefully.

## Essential Tools for Fuse Replacement

Having the right tools makes the job simple. Here is what you should keep in your glove box:

- **A Fuse Puller:** Most fuse boxes include a small plastic fuse puller clipped to the side of the panel. If you don't have one, a pair of needle-nose pliers will work, but be careful not to break the fuse.
- **A Test Light or Multimeter:** A

simple test light is invaluable for checking if a fuse has power on both sides. This confirms the fuse is good without removing it.

- **An Assortment of Fuses:** Buy a variety pack of ATO or ATC fuses (the standard blade type). Make sure it includes 5A, 7.5A, 10A, 15A, 20A, 25A, and 30A fuses. For the under-hood box, you may also need a few maxi fuses (30A, 40A, 50A).
- **Your Owner's Manual:** This contains the official **2000 Mercury Grand Marquis fuse box diagram** and is the most reliable reference.

## Safety First: When to Call a Professional

While replacing a fuse is a simple DIY task, not all electrical problems are. You should seek professional help if you encounter any of the following:

- **Fuses blow repeatedly:** This indicates a short circuit or an overloaded circuit. Continually replacing a fuse without fixing the underlying problem can cause a fire.
- **Burning smell or visible smoke:** This is a clear sign of a

serious electrical fault. Disconnect the battery and have the vehicle towed to a repair shop.

- **Large gauge wiring damage:** If wires are melted or the insulation is vaporized, the repair requires professional wiring knowledge.
- **Airbag system issues:** The Supplemental Restraint System (SRS) uses its own backup power source and sensors. Tampering with this system without proper training can lead to accidental deployment and injury.

## Where to Find a

## Reliable Diagram Online

If your owner's manual is lost and the print on the panel cover is unreadable, you can find a digital copy of the **2000 Mercury Grand Marquis fuse box diagram** from several sources:

- **Manufacturer Websites:** Ford's official owner resource site often has digital copies of owner's manuals and wiring diagrams for older models.
- **Automotive Forums:** Dedicated Crown Victoria and Grand Marquis forums (like GrandMarq.NET) are treasure troves of information.

Many users have posted high-resolution scans of their fuse box diagrams.

- **Online Parts Retailers:** Websites that sell OEM parts sometimes have diagrams available for reference purposes.
- **Automotive Libraries:** Some

public libraries offer free access to professional repair databases like Alldata or Mitchell1, which include factory wiring diagrams and fuse box layouts.

When using an online source, double-check that the diagram matches your specific year (